

Thanks for purchasing one of our Triton MC Series Horn Kits!



Components and Installation Instructions

NOTE: Be sure to mount your amplifier unit in a dry location.

You can wrap your amplifier in a plastic bag after it is mounted under the hood or other location to help keep it dry and out of direct water contact. The sound will go through the thin plastic bag without any noticeable decrease in sound volume.

Your vehicle must have a 12 volt power source to hook up this horn unit.

Check out our videos explaining exactly how this horn unit functions and how to hook it up.

<http://www.boomblasters.com/tutorials/>

TIP: Read through entire instructions carefully before beginning the installation process.

Triton MC Series Kit Components

1. Amplifier unit
2. 2 X 3"x3"x3" weather resistant horns. Some kits may have different horn color variations and sizes.
3. Wireless Remote Control Unit
4. 1 GIG USB thumb drive (to play and store your music)
5. Wiring harness
6. 8 x Screws, 2 x Speaker Mounting Plates
7. Instructions

Tools - Parts Needed (not provided):

1. Pliers
2. Tape for wiring connections
3. Wrench or suitable tool to connect power wires to battery (or other power source)
4. Bolts & nuts to mount it down
5. A few tie downs straps to safely secure the wiring
6. Computer w/USB port (To upload your preferred sound files to the thumb drive)

Installation should take around 20 to 30 minutes.

Boom Blasters "Triton MC Series Horn Kit"
<http://www.BoomBlasters.com>

Caution! Caution! Caution! Caution! Caution! Caution! Caution!

1. Do not install this unit while the vehicle is running!
2. When the unit is installed, ensure the wiring harness power lead wires are attached to a good known power source...to either the battery or a convenient fuse block. Red to Red (Positive), Black to Black (Negative).
3. Secure the unit properly and ensure the unit and all wiring are clear of any moving parts (i.e. fan belts, etc.) or items that can cause damage to the unit.

Triton MC Series
Installation Instructions

NOTE: If you do not feel comfortable installing the Triton MC Series Horn Kit, please seek qualified professional assistance.

Step 1: Battery Connection

- a. Install the Sonic Series Amplifier somewhere in the interior of your vehicle and away from any moving parts or areas that may cause damage to the Amp or the vehicle. **(The wiring harness red and black wires needs to be able to reach a good power and ground source.)**
- b. Connect the black wire from the wiring harness to the negative (-) side of the battery.
- c. Connect the red wire from the wiring harness to the positive (+) side of the battery.

Note:

- 1) **Ensure all connections are tightened properly!**
- 2) **Route wires neatly away from any moving parts to prevent damage.**

Step 2: Speaker Installation

Install the speaker(s) in a convenient location, but ensure the speaker wires will reach the unit.

Note: Route the speaker wires neatly away from any moving parts to prevent damage. The sound volume of the unit may vary depending on the placement of the speaker(s).

That's it! now go and hook up your Triton MC Series horn kit.

If you are having troubles understanding the above procedures, then please refer to the tutorial videos that are right here for you to watch!

<http://www.boomblasters.com/tutorials/>

Remember to mount your speakers and amplifier unit in a dry location.

Enjoy your Boom Blasters "Triton MC Series Horn Kit!"
